

Valley AutoPilot Control Panel for Linears

The GPS Ready Valley AutoPilot allows your linear to automatically perform functions that previously had been specific to the Valley center pivot. The AutoPilot measures the lateral position and direction of travel of the linear, allowing functions to be programmed to run automatically.

The following can be programmed to automatically function on the AutoPilot:

- Primary and secondary end guns turned on and off
- Change in speed, resulting in a change in application depths
- Application of chemicals
- Reverse or stop



Auto Pilot Control Panel

 [\[Download Brochure \]](#)